

Champion RC300

OPERATIONS MANUAL

Care & Maintenance Instructions

- Do not discard this manual.
- Keep manual readily available for reference during operation or when servicing product.
- Before operation and maintenance, read and comprehend operations manual content.
- Customer Service: 800.356.NUMA or 860.923.9551
- **Email:** numa@numahammers.com
- Website: www.numahammers.com
- Mailing Address: P.O. Box 348, Thompson, CT 06277 USA

Patents: 6,883,618 7,442,074 10,612,310 11,085,242 EP 3 803 032 B1 KR-101340351 EP-2029325 CN-101448608 BR-P10711711 AU2007254317 AU2007254317 WO2007/136658



	TABLE OF CONTENTS	Page
Section I	General Description	
	ctional Description	
1.		
2.	Connector Pins	2
3.		
4.	Check Valve	
5.	Check Valve Spring	
6.	Collection Tube	
7.		
8.	Belleville Washers	
9.	Feed Tube Housing	3
10.	Feed Tube Compression Ring	
11.	Feed Tube	
12.	Piston	
13.		
14.	Bit Bearing	
15.	Snap Ring	3
16.	Bit Retaining Rings	
17.		
18.		
19.		
20.	Drive Plates	4
Disa	Maintenancessemblyection	5
	eral Assembly	
	d Tube Assembly	
	mer Assembly	
	, , , , , , , , , , , , , , , , , , , ,	
Section III	Parts Identification	14
	llenger RC300 Exploded View	
Part	Number Reference	14 & 15
Section IV	Air Consumption Chart	16
Section V	Lubrication	
Section V	Storage	40
	_	
	rt Term	
	g Term tarting	
Resi	.ar ung	19
Section V	II Button Bit Maintenance	20
	eral	
Shai	rpening	20
	III Recommended Spares	
Chal	llenger RC300 Recommended Spares	21



LIMITED WARRANTY

Numa warrants that the Product will be new and free from defects in material and workmanship under normal use as contemplated by this Contract for a period of six (6) months from the date of shipment.

Except for the foregoing warranty, Numa disclaims all warranties and representations wherever made, including warranties of merchantability, durability, length of service, or fitness for a particular purpose.

Any alteration or modification of the original product without the express written consent of Numa will void this warranty.

REMEDY

If, during such warranty period, Buyer promptly notifies Numa in writing of any defect and establishes that the above warranty is not met, Numa shall either repair or replace the Product or credit the customer, as it deems necessary to meet the warranty.

Such repair, replacement, or credit of Product shall constitute complete fulfillment of Numa's obligation under this warranty, and upon the expiration of the original warranty period, all of Numa's obligations hereunder shall terminate.

LIMITATION OF LIABILITY

Numa shall not be liable to Buyer whether in contract, in tort (including negligence and strict liability), under any warranty or otherwise, for any special, indirect, incidental or consequential loss or damage whatsoever, including (without limitation) loss arising from delay, cost or capital and loss of profits or revenues. The remedies set forth in this Contract are exclusive, and the total cumulative liability of Numa under this Contract or for any act or omission in connection therewith or related thereto, whether in contract, in tort (including negligence and strict liability), under any warranty or otherwise, is limited to the price paid by Buyer for the Product.

The WARNINGS, CAUTIONS and NOTES used throughout the text of this instruction book are defined as follows:

WARNING A specific procedure or practice that must be strictly followed,

or a specific condition that must be met, to prevent possible

bodily harm.

CAUTION A specific procedure or practice that must be strictly followed.

or a specific condition that must be met, to prevent damage

to the equipment.

NOTE Important supplemental information.

Numa®, Champion®, and Patriot® are registered trademarks of Numa.



SECTION I DESCRIPTION

GENERAL DESCRIPTION

The Champion RC300 is a valveless, pneumatically operated reverse circulation drill designed to utilize Numa 30" to 38" (762 mm to 965 mm) diameter reverse circulation bits in a wide range of drilling applications.

The Champion RC300 hammer design incorporates a hardened case and a large diameter collection tube. The large bore design of the Champion RC300 provides high performance levels as associated with other Numa down hole hammers.

The Champion RC300 was specifically designed to provide maximum performance on the drill rigs that are most commonly used in large diameter drilling applications. The Champion RC300 hammer is designed to operate using air pressure from 100 PSI to 200 PSI (6.9 Bar to 13.8 Bar) with compressors having 3000 CFM (1417 Litres/Second) or more.

Cham	pion RC300	
Weight w/o Bit Outside Diameter Hammer Length:	11584 lbs. 28"	(5266 kg) (711 mm)
Shoulder to Shoulder Shoulder to Bit Face	93" 110"	(236 cm) (279 cm)

Table 1-1 General Hammer Specifications

30"	(762 mm)	* 3847 lbs.	(1749 kg)
32"	(813 mm)	* 4172 lbs.	(1896 kg)
34"	(864 mm)	* 4497 lbs.	(2044 kg)
36"	(914 mm)	* 5022 lbs.	(2283 kg)
38"	(965 mm)	* 5301 lbs.	(2405 kg)

Table 1-2 General Bit Specifications

NOTE

NUMA 30" TO 38" (762 MM TO 965 MM) BITS ARE AVAILABLE IN A CONCAVE FACE DESIGN WITH A LARGE CENTER COLLECTION TUBE TO TAKE ADVANTAGE OF THE CHAMPION RC300 PERFORMANCE. OTHER SIZES MAY BE AVAILABLE UPON REQUEST.

^{*} Bit weights are approximate



FUNCTIONAL DESCRIPTION

1. BACKHEAD



The backhead connects the hammer to the drill rod. Backheads can be manufactured to be compatible with several reverse circulation drill rod designs. Please contact your distributor or regional salesperson for more information. Wrench flats are provided for disassembly.

2. CONNECTOR PINS



The connector pins are located on the top of the backhead, in the wirth flange. These pins allow air to flow into the hammer via the adaptor/drill rod.

3. CHECK VALVE SEAT



The check valve seat provides the sealing surface for the check valve and guides the collection tube.

4. CHECK VALVE



The check valve maintains pressure in the hammer when the air supply has been shut off. The check valve in the hammer balances the hydrostatic pressure in the hole thereby preventing contaminants from entering the hammer.

5. CHECK VALVE SPRING



The check valve spring provides tension under the check valve to keep it closed. It is compressed as the air is turned on.

6. COLLECTION TUBE



The collection tube extends from the backhead to the bit and transfers the collected drill cuttings to the inner drill pipe of the reverse circulation drill rod. The collection tube is designed to be easily replaced without removing the backhead from the drill.

7. COLLECTION TUBE HOUSING



The collection tube housing aligns the collection tube. Holes in the collection tube $^{\prime}$ housing provide the necessary porting supply air.

8. BELLEVILLE WASHERS



Two belleville washers sit between the collection tube housing and the feed tube housing to keep the feed tube housing tight against the shoulder in the hammer.




9. FEED TUBE HOUSING



The feed tube housing is aligned in the main bore of the hammer. It sits against a shoulder in the case and is held in position by the backhead, collection tube housing and belleville washer combination. The feed tube housing locates and aligns the feed tube.

10. FEED TUBE COMPRESSION RING



11. FEED TUBE



The feed tube supplies the main air into the chambers located in the piston. It seats on a shoulder in the feed tube housing and is designed with a long bearing surface to maintain alignment in the feed tube housing.

12. PISTON



The piston functions as the only moving part in the hammer, controlling the operational air cycle. The percussive action of the piston striking the bit transfers the energy through the bit in order to fracture rock formations.

13. CASE



The case is designed to contain the internal parts which make up the hammer assembly. The case is hardened to resist wear and to extend life in abrasive conditions.

14. BIT BEARING



The bit bearing guides the top end of the bit to insure proper alignment between the piston and the bit. The bit bearing is positioned in the chuck end of the case and is held in place by the snap ring.

15. SNAP RING

The snap ring sits in a groove in the case and retains the bit bearing.




16. BIT RETAINING RINGS



The bit retaining rings are designed to allow the bit to move between the drilling and cleaning positions and prevent the bit from coming completely out of the hammer. The bit retaining rings consist of two matched halves and are held together with the bit retaining ring o-ring.

17. THRUST WASHERS



18. CHUCK



The chuck threads into the bottom end of the case with a large cross section thread form. It has internal splines that transmit rotation to the bit through a set of delrin drive plates.

19. CHUCK BUSHING

The chuck bushing is a nylon insert located in the bottom end of the chuck to provide \nearrow a bearing surface between the lower bit shank and the chuck.

20. DRIVE PLATES



The plastic drive plates provide wear protection for the splines. They are inserted between the chuck and the bit. A complete drive plate set (12) is sent with each bit.



SECTION II MAINTENANCE

DISASSEMBLY

• Maintenance should be performed in a clean environment.

CAUTION

USE CAUTION WHEN HANDLING DOWN THE HOLE HAMMER PARTS. NUMAHAMMER PARTS ARE MANUFACTURED FROM HARDENED, HEAT TREATED MATERIALS. DROPPING OR STRIKING THESE PARTS MAY CAUSE SEVERE DAMAGE. STRIKING THE HAMMER PARTS WITH HAMMERS, CROWBARS OR LIKE INSTRUMENTS WILL VOID THE WARRANTY.


- Tools needed: hammer stand, 26" (660 mm) "J" or fork wrench (possibly incorporated in the hammer stand), overhead crane or lift truck, pulldown visetong with a 28" (711 mm) diameter capacity or a self contained power wrench capable of 200,000 foot pounds of torque, lifting eyes, 2" (51 mm) diameter brass rod or mild steel rod 3 to 5 feet (1 m to 1.5 m) long, snap ring pliers, chains, lifting slings, a drift pin and several difference sized screwdrivers.
- Clean the outside of the hammer. This will insure a good surface to clamp on.
- With the hammer in a vertical position, remove the collection tube. The collection tube is equipped with two 1/2" UNC threads for lifting eyes.
- The collection tube can be replaced without disassembly of the hammer. Prior to removal of the collection tube, pressure wash the inside diameter of the collection tube to remove any cuttings or debris. The collection tube is equipped with two 1/2" UNC tapped holes for lifting eyes to facilitate removal. With the hammer in a vertical position, use an overhead crane or lift truck of appropriate capacity to remove the collection tube. Thoroughly lubricate the collection tube O.D. and reverse the process to install the new collection tube.

CAUTION

FAILURE TO THOROUGHLY CLEAN THE COLLECTION TUBE BEFORE REMOVAL MAY ALLOW FOREIGN MATERIAL TO CONTAMINATE THE HAMMER.

Using an overhead crane or lift truck of appropriate capacity, place the hammer on a
hammer stand and secure it in the wrench. The chuck end can be held by the 26" (660
mm) flats, in the wrench. The backhead is also held in the 26" (660 mm) wrench. Place
the visetongs on the area of the case where the bit bearing is located when working on
the chuck end of the hammer. When working on the backhead end of the hammer, place
the chain vise on the area of the case where the feed tube housing in located.





Hammer Stand/Wrench Diagram Figure 2-1

CAUTION

THE ACCEPTABLE CLAMPING AREAS START 11.500" (292 MM) FROM EITHER CASE END, TO AN ADDITIONAL 10" (254 MM) BEYOND THIS POINT. PLACING THE VISETONG ON THE AREA OF THE CASE WHERE THE PISTON CYCLES CAN DISTORT THE CASE, RESTRICT PISTON MOVEMENT AND VOID THE WARRANTY.

- With the chuck secured in the fork wrench, (see figure 2-1) loosen the joint by turning
 the case with the visetongs. Remove the hammer from the wrench and turn the hammer
 end for end in the hammer stand / wrench. With the backhead flats secured in the fork
 wrench (see figure 2-1) loosen the joint by turning the case with the visetongs.
- Remove the connector pins from the top of the flange.
- With the crane or lift truck, move the hammer into an upright position with the chuck end down. With an adequate lifting device, lift and support the hammer while unscrewing the chuck. After setting the hammer down, and while lifting and supporting the backhead, unscrew and remove the backhead from the case.
- Remove the backhead o-ring and thrust washer from the backhead.
- Remove the collection tube o-ring from the backhead I.D. on the drill rod mating end.
- Remove the check valve seat, the check valve and the check valve spring from the backhead end of the case. The check valve seat is equipped with two 1" UNC tapped holes for lifting eyes to facilitate removal.



- Using a small screwdriver, pick the check valve seat o-ring from the outside diameter of the check valve seat.
- Remove the collection tube housing. The collection tube housing is equipped with two 1" UNC tapped holes for lifting eyes to facilitate removal.
- Using a screwdriver, pick the two o-rings from the inside diameters of the collection tube housing.
- Remove the belleville washers.
- Remove the feed tube assembly. The feed tube assembly is equipped with two 1" UNC tapped holes for lifting eyes to facilitate removal.
- Raise the piston out of the backhead end of the case by inserting two 8" (203 mm) long, 1.625" (41 mm) diameter steels rods into the holes inside the piston. Put one rod in the bottom and another rod 180 degrees opposite in the top hole. Lift the piston out with nylon straps and a suitable lifting device.
- Remove the thrust washer from the chuck.
- Remove the bit retaining rings o-ring from the bit retaining rings.
- Removal of the chuck bushing is not necessary for routine maintenance. If necessary, lay the chuck on its side so that the bit end is facing you. Locate the seam in the chuck bushing. Insert a screwdriver into the slot in the middle of the seam and pry the chuck bushing from the under cut. Remove the chuck bushing from the bit end of the chuck.
- Removal of the bit bearing and snap ring in the chuck end of the case is not necessary
 routine maintenance. If necessary, remove the snap ring from the groove. Press the bit
 bearing out the chuck end of the case.
- Disassembly of the feed tube assembly is not necessary for routine maintenance. If necessary, support the feed tube housing and suspend it in the air. Remove the feed tube snap ring with a large screwdriver. Lower the feed tube assembly until the feed tube contacts the work bench. The weight of the feed tube housing will let it ride down the outside of the feed tube. Wrap a nylon strap around the flange of the feed tube and lift it out of the feed tube housing. Slide the feed tube compression ring off the the feed tube. (See figure 3-2 for the feed tube assembly exploded view diagram) Place the feed tube collar toward the work bench. Using a small screwdriver, pick the feed tube o-ring from the grooves in the feed tube housing and the three orifice o-rings from the inside diameter of the feed tube.



INSPECTION

 All parts should be washed in a clean solvent before they are inspected and reassembled.

WARNING

USE CLEANING FLUIDS THAT ARE NONFLAMMABLE AND AVOID BREATHING THE FLUID VAPORS.

• Handle all parts carefully, hardened parts may chip if dropped on a hard surface.

BACKHEAD

- Inspect the threads for cracks and burrs.
- Remove all burrs on the thread with a fine file.
- Replace if necessary.

CHECK VALVE SEAT

- Inspect the outside diameters for nicks, burrs and scoring.
- Remove all minor irregularities with emery cloth.
- Replace if necessary.

CHECK VALVE / CHECK VALVE SPRING

- Inspect the outside diameters for nicks, burrs and scoring.
- Remove all minor irregularities with emery cloth.
- Replace if necessary.

COLLECTION TUBE & COLLECTION TUBE HOUSING

- Inspect the outside diameters for nicks, burrs and scoring.
- Remove all minor irregularities with emery cloth.
- Check the I.D. size (at the chuck end) of the collection tube. The tube I.D. should be no bigger than 7" (178 mm).
- Inspect the weld at the collar for cracks.
- Replace if necessary.



CONNECTOR PINS

- Inspect for cracks or burrs.
- · Remve burss with file or emery cloth.
- Replace if necessary.

BELLEVILLE WASHERS

- Inspect the belleville washers for severe wear indications or cracks.
- Replace if necessary.

FEED TUBE ASSEMBLY

- Inspect all makeup surfaces for indentations or nicks caused by wear.
- Remove all minor irregularities with emery cloth.
- Replace if necessary.

PISTON

- Inspect the striking face, inside and outside diameters for nicks, scoring and cracks.
- Polish the piston with emery cloth to remove all minor irregularities. Cracked pistons should be replaced.
- Wash the piston thoroughly, inside and out, to remove all emery dust.
- Replace if necessary.

CASE

- Inspect the outside diameter for excessive wear or cracks. Inspect the internal case bore for scoring.
- Remove all minor irregularities with fine honing stones.
- Clearance between the piston and the case should not exceed 0.030" (0.76 mm).
- Replace if necessary.



BIT BEARING

- Inspect the inside and outside for nicks and burrs.
- Remove all internal irregularities with a fine honing stone.
- Remove all external irregularities with an emery cloth.
- Clearance between the bit shank and bit bearing should not exceed 0.048" (1.21 mm).
- Replace if necessary.

SNAP RING

Inspect the snap ring for severe wear indicators. Replace if necessary.

BIT RETAINING RINGS

- Inspect for cracks or deformations.
- · Remove all irregularities with a file or emery cloth.
- Replace if necessary.

THRUST WASHERS

Inspect for damage such as cracks and deformations. Replace if necessary.

CHUCK

- Inspect for cracks and burrs.
- For continued use, the outside diameter should be larger than the outside of the case or the same. Collar length should not be less than 6.750" (172 mm).

CAUTION

IF THE COLLAR LENGTH IS LESS THAN 6.750" (172 MM) AND THE BIT IS UNDER LOAD CONDITIONS, CONTACT BETWEEN THE SHOULDER OF THE BIT RETAINING RINGS AND THE BOTTOM OF THE BIT RETAINING RING AREA ON THE BIT, COULD CAUSE THE BIT TO FAIL IN THIS AREA.

- Torsional play in the splines should not exceed 0.375" (9.5 mm).
- Replace if necessary.



CHUCK BUSHING

Inspect for damage such as cracks and deformations. Replace if necessary

O-RINGS

Inspect for damage such as cracks and deformations. Replace if necessary.

DRIVE PLATES

• Inspect for damage such as cracks and deformations. Replace if necessary.

GENERAL ASSEMBLY INSTRUCTIONS

- Assembly should be performed in a clean environment.
- All parts should be cleaned thoroughly and wiped dry before assembly.
- Oil all parts by hand using Rock Drill Oil to insure easy assembly.
- Coat all thread connections and thrust washers with a thread compound to allow joints to thread easily.

FEED TUBE ASSEMBLY

- Install the two feed tube o-rings in the two grooves located in the smallest inside diameter of the feed tube housing.
- Insert the three orifice o-rings into the groove at the inside diameter of the feed tube.
- Place the feed tube compression ring over bottom end of the feed tube, then slide it along the feed tube until it seats against the feed tube collar.
- Position the piston vertically. Place the smallest outside diameter of the feed tube housing on the piston so that the bores will align. Insert the small end of the feed tube into the feed tube housing. Slide the feed tube into the feed tube housing until the feed tube compression ring seats against the feed tube housing shoulder. While applying pressure to the feed tube collar to expose the snap ring groove, use a large screwdriver to insert the feed tube snap ring. Remove the feed tube assembly from the piston.



HAMMER ASSEMBLY

- Using the overhead crane, turn the hammer case upside down in a vertical position so that the bit bearing bore is facing up.
- Insert the bit bearing into the chuck end of the case. This should be a close slip fit. Making sure the bearing makes contact with the shoulder provided for it in the case, insert the snap ring into the groove at the chuck end of the bit bearing diameter.
- Using the overhead crane, turn the hammer case so that the backhead end is facing up. The hammer case should still be in a vertical position.
- Lower the piston into the backhead end of the case using the 8" (203 mm) long steel rods, 1.625" (41 mm) diameter steel rods and the nylon straps.
- Install the feed tube assembly into the backhead end of the case, making sure it is firmly
 against the shoulder in the case. Due to close tolerances, caution is advised when
 inserting the feed tube assembly. It should not be forced into the case.
- Install the believille wahsers in the counter bore of the feed tube assembly. See the stacking diagram on page 14 for proper installation.
- Install the collection tube housing o-ring and the collection tube o-ring in the I.D. of the collection tube housing.
- Install the collection tube housing. The collection tube housing will rest on the belleville washers.
- Place the check valve spring and check valve on the collection tube housing.
- Install the check valve seat o-ring into the groove on the outside diameter of the check valve seat.
- Lower the check valve seat through the check valve and check valve spring. Make sure the check valve seat is seated into the collection tube housing.
- Assemble the backhead o-ring into the groove in the backhead. Install the collection tube o-ring in the groove in the backhead on the drill rod mating end. With the thrust washer installed on the case shoulder, thread the backhead into the case and tighten until the shoulder is tight against the case.
- Install the connector pin o-rings on the connector pins. Using a soft blow hammer, seat the (2) connector pins into the flange openings on the top of the backhead.

NOTE


DUE TO THE INTERNAL COMPRESSION SPRINGS, THE CHAMPION RC300 BACKHEAD CAN ONLY BE FULLY TIGHTENED WITH A POWER WRENCH ON THE RIG.



CAUTION

LIFTING THE CHAMPION RC300 HAMMER WITH THE THREAD JOINTS LOOSE MAY CAUSE DAMAGE TO THE THREADS.

• Install the chuck bushing in the chuck. With the bit face down, place the chuck over the top of the bit. Align the splines and lower the chuck completely onto the bit. Rotate the chuck counterclockwise until the splines meet and insert the drive plates between the chuck and bit splines. (See Figure 2-2)



RC300 Drive Plate Positioning as Viewed from Top Figure 2-2

- Place the bit retaining rings, with the o-ring installed, over the chuck.
- Place the thrust washer against the chuck thread shoulder. Thread the chuck into the case and hand tighten. The chuck should sit flat against the end of the case.
- With the hammer in a vertical position and the bit installed, insert the collection tube.

NOTE

THE COLLECTION TUBE SHOULD BE ASSEMBLED WITH THE BIT INSTALLED IN THE HAMMER AS THE COLLECTION TUBE, WHEN ASSEMBLED, PROTRUDES FROM THE BOTTOM OF THE HAMMER 6.500" (165 MM).

NOTE


LUBRICATING THE OUTSIDE DIAMETER OF THE COLLECTION TUBE PRIOR TO ASSEMBLY IS NECESSARY TO FACILITATE ASSEMBLY.

CAUTION

DUE TO CLOSE TOLERANCES BETWEEN THE CHAMPION RC300 INTERNAL PARTS AND THE CASE, NUMA CANNOT ACCEPT RESPONSIBILITY FOR DAMAGED CAUSED BY WELDING ON THE CASE OD. WELDING ON TEH CASE CAN CREATE DISTORTION, CAUSE PREMATURE FAILER AND VOID THE WARRANTY. CONTACT NUMA FOR SPECIAL INSTRUCTIONS IF WELDING THE CASE BECOMES UNAVOIDABLE.




SECTION III PARTS IDENTIFICATION



Champion® RC300



SECTION III PARTS IDENTIFICATION EXPLODED VIEW




FEED TUBE ASSEMBLY #008922 Figure 3-2



SECTION IV AIR CONSUMPTION CHARTS CHAMPION RC300

DRILL PRESSURE (BAR)



^{*} Operation Above 250 PSI (17 BAR) Is Not Recommended.

NOTE

Numa RC hammers utilize an orifice o-ring as a choke. Removal of the orifice o-ring allows additional air to pass through the hammer for hole cleaning/flushing purposes.

Champion® RC300



SECTION V LUBRICATION

The Champion RC300 hammer requires a continuous supply of the correct type Rock Drill Oil. The Champion RC300 hammer consumes at least 20 quarts (19 litres) of Rock Drill Oil per hour in order to maintain adequate lubrication. When using Biodegradable Oils, you must increase the total amount by 25%. See table 5-1 for recommended Rock Drill Oil.

	Medium SAE 30	Heavy SAE 50
Shell	Air Tool Oil S2 A 150	Air Tool Oil S2 A 320
Texaco / Caltex	Rock Drill Lube 100	Rock Drill Lube 320
Chevron	Vistac 150	Vistac 320
Conoco	Conoco 150	Conoco 320
Numa Bio Blend	RDP 150	RDP 320

Table 5-1
Recommended Rock Drill Oil

CAUTION

ROCK DRILL OILS ARE THE ONLY ACCEPTABLE LUBRICANTS. SAE 50 ROCK DRILL OIL SHOULD BE USED IN AMBIENT TEMPERATURES OF 80° FAHRENHEIT (27° CELSIUS) OR HIGHER. CONTACT NUMA FOR ACCEPTANCE OF ALTERNATIVE ROCK DRILL LUBRICANTS.

CAUTION

THE CHAMPION RC300 HAMMER, AS WITH ANY MACHINE, REQUIRES CONTINUOUS LUBRICATION. THE FAILURE TO SUPPLY ADEQUATE LUBRICATION TO THE HAMMER CAN CAUSE PREMATURE FAILURE AND MAY VOID THE WARRANTY.



SECTION VI STORAGE

When storing a Champion hammer, it is important to take the necessary steps in order to insure a smooth operation after restarting.

When the hole is completed and the hammer is to be inactive for several weeks or longer the following steps should be followed:

Each drill rod should be blown clear of all water. During this process, turn on the in line lubricator and blow until the rock drill oil can be seen from the bottom end of each drill rod. In addition, each rod (pin and box end) should be wiped clean and capped to prevent foreign contaminants from sticking to the connector ends.

SHORT TERM STORAGE

When the Champion hammer will be stored for only a short period of time the following steps should be taken:

- Blow the hammer clear of all water.
- Pour one cup of Rock Drill Oil into the backhead.
- Turn the air on and cycle for 10 seconds. This will lubricate the internal parts.
- Cap the backhead and chuck end.
- Store the hammer horizontally in a dry environment.

LONG TERM STORAGE

When the Champion hammer will be stored for only a long period of time the following steps should be taken:

- Blow the hammer clear of all water.
- If at all possible, the backhead and chuck should be broken loose on the drill rig, this is much easier than trying to do so in the shop.
- Disassemble the hammer.
- Inspect and wipe all the parts clean.



- Lubricate all the internal parts with Rock Drill Oil. See table 5-1 on page 16 for suitable Rock Drill Oils.
- Cap the backhead and chuck ends.
- Store the hammer horizontally in a dry environment.

RESTARTING

Before restarting the hammer after prolonged periods of inactivity, disassemble and inspect all internal hammer parts.

If any internal hammer parts have oxidized, use an emery cloth to polish each part. Wash each hammer part, wipe dry, relubricate with rock drill oil and reassemble the hammer.

CAUTION

FAILURE TO CHECK INTERNAL PARTS BEFORE RESTARTING THE HAMMER MAY CAUSE SERIOUS DAMAGE TO THE HAMMER.



SECTION VII BUTTON BIT MAINTENANCE

GENERAL

Numa button bits are designed for fast penetration and long life. Keeping the carbide buttons sharp has a direct effect on both the penetration and the tool life.

As the bit wears flat, spots develop on the carbide buttons. These flat spots increase stress on the buttons causing the bit to work harder, which may cause button failure. Bit sharpening can minimize these problems.


Gauge buttons will usually show the most wear and should be used to determine the frequency of bit sharpening. When the flats on the gauge buttons become a maximum of 1/8" (3 mm) wide it is time to resharpen. Refer to figure 7-1.

SHARPENING

The following tools are required to resharpen the bit:

- Hand grinder (20,000 r.p.m.)
- Silicon carbide wheel 1" (25 mm) diameter, 60 80 grit
- Bit stand
- Pencil

Place a mark on the center of the button flat. Grind the button to its original shape leaving the mark untouched. Refer to figure 7-1. It is important to leave the center of the flat untouched to insure concentricity.



Button Resharpening Figure 7-1



SECTION VIII RECOMMENDED SPARES CHAMPION RC300

Product Description	Part Number	Class 1	Class 2
Collection Tube	018573	4	8
Collection Tube O-Ring	008919	2	4
Connector Pin Wirth	013613	2	4
Connector Pin Wirth O-Ring	005895	4	8
Backhead Wirth Flange Mount	008907	0	1
Backhead O-Ring	008913	2	4
Thrust Washer - Brass	008928	2	4
Check Valve Seat	008914	0	1
Check Valve Seat O-Ring	008926	2	4
Check Valve	008915	1	2
Check Valve Spring	008916	1	2
Collection Tube Housing O-Ring	008918	2	4
Collection Tube O-Ring	008919	2	4
Collection Tube Housing	008917	0	1
Belleville Washer	008921	0	2
Feed Tube Assembly	008922	1	2
Feed Tube Snap Ring	008928	1	2
Feed Tube	008929	1	2
Orifice O-Ring	008919	3	6
Feed Tube Compression Ring	008930	1	2
Feed Tube O-Ring	008931	2	4
Feed Tube Housing	008912	0	1
Piston	008906	1	2
Case	015065	0	1
Bit Bearing	008909	1	1
Snap Ring	008911	1	2
Bit Retaining Rings	008910	1	1
Bit Retaining Ring O-Ring	008913	2	4
Chuck	008904	1	2
Chuck Bushing	008908	1	2

For Complete Hammer Assembly #019083 Table 8-1

	NOTE
Class 1	Represents a user of a Champion RC300 hammer that has readily available spare parts.
Class 2	Represents a user of a Champion RC300 hammer that does not have readily available spare parts.



NOTES

Page 22 — Champion® RC300 — 11/06/2024 J



NOTES

Champion® RC300 ———— Page 23